

THE ORIGINAL
FATSAC
 BALLAST BAG CO.

Barefoot International & Fly High Mfg.
 3879 North Richards Street
 Milwaukee, WI 53212

PHONE 414-964-3668 ■ FAX 414-964-5767 ■ E-MAIL orders@fatsac.com ■ WEB www.fatsac.com



PART#	DESCRIPTION	• Fittings made for automatic ballast systems
W730	FEMALE QUICK CONNECT W/CHAIN & CAP — SAC VALVE THREADS	
W739	QUICK CONNECT CAP	
W731	FAT SAC PLUGS — SAC VALVE THREADS	
W732	FEMALE GHT — MALE QUICK CONNECT	
W733-SS •	1" BARBED END — SAC VALVE THREADS — SHOULD USE PERMANENT EPOXY CEMENT (W720)	
W734	MALE QUICK CONNECT — TSUNAMI PUMP THREAD	
W735	FEMALE QUICK CONNECT — BLUE PERFECT UNION FITTING	
W736-SS •	3/4" QUICK CONNECT — SAC VALVE THREADS — SHOULD USE PERMANENT EPOXY CEMENT (W720)	
W737 •	3/4" BARBED END — SAC VALVE THREADS — SHOULD USE PERMANENT EPOXY CEMENT (W720)	
W738	MALE QUICK CONNECT — 1-1/8" BARBED TSUNAMI PUMP HOSE END	
W740 •	FLOW-RITE 3/4" STRAIGHT QUICK CONNECT SOCKET	
W741 •	FLOW-RITE 1-1/8" STRAIGHT QUICK CONNECT SOCKET	
W742 •	FLOW-RITE 3/4" ELBOW QUICK CONNECT SOCKET	
W746 •	FLOW-RITE 1-1/8" ELBOW QUICK CONNECT SOCKET	
W746-PLUG •	FLOW-RITE 1-1/8" PLUG FITS INSIDE W746/W741 FITTINGS TO CAP OFF PNP SYSTEMS IN BOATS — COMES WITH DOUBLE O-RINGS FOR BEST SEAL	
W743-DOUBLE •	DOUBLE SIDED 1-1/8" QUICK CONNECT FITTING	
W743-SS •	SUCTION STOP SAC VALVE THREADS — 1-1/8" QUICK CONNECT — SHOULD USE PERMANENT EPOXY CEMENT (W720)	
W744	PRO X SERIES CHECK VALVE — ALL CHECK VALVES SLIGHTLY HINDER FLOW	
W745 •	3/4" BARBED TSUNAMI PUMP FITTING	
W747 •	SAC VALVE THREAD FOR TSUNAMI PUMP — SHOULD USE PERMANENT EPOXY CEMENT (W720)	
W748 •	1-1/8" QUICK CONNECT TO 1" BARBED	
W749	AIR RELEASE PLUG — TURN TO RELEASE AIR. FOR MANUAL FILLING, NOT FOR VENTING AUTOMATIC SYSTEMS.	
W753 •	1" BARBED IN-LINE CHECK VALVE	
W755 •	1-1/8" BARBED IN-LINE CHECK VALVE	
W766	SUPA PUMP ZURU BALLOON ADAPTER ACCESSORY	
W720	EPOXY CEMENT FOR FITTINGS, 25ML OR 1 OZ TUBES (AKA:50805) — MIX WELL BEFORE USE!	

NOTE: There are many possible combinations using our Quick Connect fittings. If you are trying to accomplish something and aren't sure how to best handle it, please contact us and we will be glad to help.

IMPORTANT: Use All-Purpose PVC Cement on the threads of the W733-SS, W736-SS, W737, W743-SS, and W747 when screwing them into Fat Sacs.